



- 5.** Apply a bead of neutral cure sealant around the base of the bath, then bed it into position.

